

## INTELLIO PC DEFAULTS

### Windows Username and Password

The Intellio Server PC's Windows are delivered with a preconfigured user named **intellio**. We recommend to use this user because the Intellio Client and VNC software are installed to this user.

Username	Password
intellio	intellio1234

The 24x7 Intellio Server PC's Windows are delivered with a preconfigured user named **Administrator**. We recommend to use this user because the Intellio Client and VNC software are installed to this user.

Username	Password
Administrator	Intellio1234

**Important:** We recommend to change this password! Do this after logging in for the first time in to Windows and pressing **Ctrl+Alt+Delete** and select **Change password**.

### Intellio Video System 4 Username and Password

The IVS4 has two built in default user accounts. The first one is called **administrator** and has full control over the Intellio Video System the second one is called **operator** and has limited control.

Username	Password
administrator	admin
operator	op

**Important:** We recommend to change these passwords! Do it after logging in for the first time in to Intellio Video System. Using the **Intellio Client** select the **System Configuration** menu from the Main Menu. Select **Security** in the tree view on the left then select **Users**. Now select the **Administrator** row in the middle of the screen and press the **Edit** button on the top. Type in the new password twice and press **OK**.