

INTELLIO VIDEO SYSTEM 5 BACKUP AND RESTORE

Backing up Intellio Video System 5

After we have set all the necessary settings and the system is working well it is recommended to make a backup from the system in case of a system crash the system can be easily restored.


Backup

The Intellio Server 5 is storing the system settings in the so called **SystemConfig.rce** and a **LocalConfig.rce** files. These files are in **c:\Program Files \Intellio Video System\ Intellio Server** folder:

- Camera names
- Camera IDs
- IP addresses
- Video Adjustment settings
- Tracker and Calibration settings
- Motion Sensor and Detector settings
- Storage Rules
- Site and Domain settings

To save the configuration files go the following inside Intellio Client 5:

System Configuration / Site / Servers / Backup Config button / Select server



Then a window appears where we can set the destination of the configuration files. The above mentioned two configuration files will be zipped into the desired location. Make sure these files are in a safe place.

In case you are using the 3D Map feature in the IVS5 it is also recommended to create a backup from the **MapData.rce** file and the **MapStore** folder. This file and folder contains the settings and parts of the 3D Map. This file is found in the Intellio Server folder (*check it in the location where you have installed the application, by default it is here: **c:\Program Files (x86)\Intellio Video System\Intellio Server***).

Restore

- **Install** the Intellio Server with default settings.
- After installing **STOP** the Intellio Server service.
- **Copy** the saved backup files into the Intellio Server folder by overwriting the default configuration files.
- **START** the Intellio Server service.